

The logo for Jeeperman, featuring the word "JEEPERMAN" in a bold, black, sans-serif font. The text is set against a dark, textured background that resembles a close-up of a vehicle's metal frame or a similar industrial surface.

## **FKT/FKY/FKC Installation Instructions**

**It would be recommended to read these instructions, in their entirety, BEFORE starting the installation. There are a couple steps that need to be followed exactly. If you are uncomfortable with these steps, please e-mail or call us for assistance or seek a qualified professional installer. Installation time: Approx. 1 Hour**

### **Tools Required:**

5/8" Wrench

### **Included Hardware:**

Grade 8 bolts, washers and flange lock nuts as required.

One pair of frame tie in brackets.

### **FK Jeeperman Frame kit Installation**

This install document is furnished as a guide; your vehicle may be different.

Some combinations may require trimming with some aftermarket shackle kits or body lifts. **Items that have been modified are not returnable or exchangeable so verify compatibility first.**

1. The YJ and CJ kit possibly will require drilling or possibly welding to the vehicle's frame if certain aftermarket shackles have been installed. The TJ and LJ 97' and up should have behind the wheel at each rear section of the frame rails 2 holes facing out and 2 holes on the outer ends of the cross member. If bumper is already installed, the cross member bolts may need to be removed and reinstalled as shown in last picture here. The frame holes will match up to each of the frame kit brackets.
2. The installation of the hardware is to place the nut into a box end wrench or may be able to do by hand sliding the flanged lock nut inside the frame and into position as shown. Access is gained up through the factory hole if so equipped on the bottom of the frame rails. A piece of tape may help to keep the nut affixed to the wrench (if using a wrench) and then install the frame bracket on the outside of the vehicle's frame with the washers and bolts loosely tightened.
3. An optional step is possible on 97' and up Wranglers and Unlimited with included hardware as shown below. Once all bolts are in place then tighten all to 40 ft. lbs with a small amount of Lok-Tite. Repeat for all bolts and then on other side.



Call 303-433-1630 or email [info@jeeperman.com](mailto:info@jeeperman.com) for support.