

The logo for Jeeperman, featuring the word "JEEPERMAN" in a bold, black, sans-serif font. The letters are set against a dark, textured background that resembles a close-up of a vehicle's front end, possibly a grille or bumper, with some light reflecting off the surfaces.

Front Bumper Installation Instructions

Inspect the packaging and product for signs of damage and report immediately to carrier. Keep all packaging for filing a damage claim if needed.

It would be in recommended to read these instructions, in their entirety, BEFORE starting the installation. If you are uncomfortable with these steps, please e-mail or call us for assistance or seek a qualified professional installer. Installation time:

Approx. 1 Hour

Tools Required:

SAE Wrenches

TORX Wrenches

Lok-Tite thread locker

Jeeperman Front Bumper Installation

This install document is furnished as a guide; your vehicle may be different. **Items that have been modified are not returnable or exchangeable so verify compatibility first.**

1. Remove any existing accessories such as lights or winches and mounts. Remove existing bumpers bolts and remove bumper. Most newer Wranglers will have 6-T-55 Torx bolts that may be re used for mounting new bumper. Remove plastic sway bar cover if so equipped. This cover may need to be removed or slightly trimmed down if re used with the Jeeperman bumper. See image for more on this.
2. If installing a winch at this time it may be easier; provided you have a helper, to pre install the winch and fairlead per manufactures instructions. Most winches are secured to our winch plate built into the bumper with 4 bolts and 2 more for the fairlead.
3. Position the bumper (and tow hooks and light hoop if installing at this time) onto the frame rails. Hand install all bolts loosely to allow for minor movement until all bolts are in place. Once all bolts are in place then tighten all to 40 ft. lbs with a small amount of Lok-Tite on the threads.
4. Install and wire any lights and finish-installing winch wiring if applicable. Re install sway bar cover if desired. Install any other accessories such as D- rings and license plate as required. The plate can either be installed using an aftermarket clip on style mount over the fairlead or can be position under the fairlead bracket and the fairlead if running a winch.



(Shown with optional light hoop and D – rings from Jeeperman)

Call 303-433-1630 or email info@jeeperman.com for support.